rond

unifit socket type J
installation instruction

1

Drill the installation hole and optional countersink.
For installation in plastered walls check the installation manual 'retrofit plaster ring type J' and proceed to step3.

2

Flush mount countersink.

3

Turn the power off.

4

Make all necessary connections.

5

Insert the socket in the hole.

6

Level the socket and fixate it by tightening the screws.

7

Tighten the screws until the clamps are fully secured.

8

Install the cover plate.

9

Turn the power on.

for removal

Turn the power off before removing the socket.

10

Remove the cover plate.

11

Loosen the screws.

12

Remove the socket.

thank you for choosing rond

RONDJO Stroer NV - Handelsstraat 19 - 8630 Veurne - Belgium

Installation must be done by skilled professionals only and instructions must be followed at all times. Warranty will not apply in case of wrongful use of it or unauthorized personnel attempts to repair a product.